

Three Color Sign Manual

****Before You Install the Sign, Please See the Sign and Make Sure Everything is Working Properly (including the Programming). This will Save a lot of Time and Cost in the Future.***

How to Add Single Line:

1. Press "Menu" button
2. When [1] Add Contents displays, press "OK" button
3. When ① Add Message displays, press "OK" button
4. Enter the Desired text by using number buttons on the remote. Press "OK" after you have finished entering your text.
 - a. IF your sentence is shorter than the screen size, choose ① Automatic. Press "OK"
 - b. IF your sentence is longer than the screen size, choose ② To Pass. Adjust the speed by pressing "Speed" button (right and left of "OK" button). Press "OK"
5. Your message has been saved.

How to Add Double Line:

1. Press "Menu" button
2. When [1] Add Contents displays, press "OK" button
3. When ① Add Message displays, press down button, and choose ② Add dual Message. Press "OK" button
4. Enter the Desired text by using number buttons on the remote. Press "OK" after you have finished entering your text.
 - a. Try to make top line smaller than the screen size. Bottom line can be as long as you want it to be.
5. Select "② To Pass" and press "Effect" buttons to choose how you want your message to be displayed. Press "OK" button after you made your selection.
6. Your message has been saved.

How to Add Pre-Loaded Image, Picture, Video:

1. Press "Menu" button
2. When [1] Add Contents displays, press "OK" button
3. When ① Add Message displays, press down button, and choose ③ Add Image, ④ Add Picture, or ⑤ Add Video. Press "OK" button
4. Scroll through the previews and choose one you like. Press "OK" button
5. Your message has been saved.

How to Display Time:

1. Press “Menu” button
2. When [1] Add Contents displays, press down button until you see [8] Set Time. Press “OK” button
3. When ① Set Time displays, press “OK” button
4. Change the time by pressing Up and Down buttons. Press “OK” button to save the current time.
5. When ① Set Time displays, press the red “esc” button. You’ll see [8] Set Time. Scroll up to [1] Add Contents again. Press “OK” button
6. When ① Add Message displays, press down button and choose ⑦ Display time. Press “OK”
7. Change colors if necessary. Press “OK” button after you made the adjustment.
8. When ① Automatic displays, Press “OK” button.
9. Current time will display on your sign.

How to Edit Your Saved Message:

1. Press “Menu” button
2. When [1] Add Contents displays, press down button until you see [2] Modify Contents. Press “OK” button
3. Scroll down to the message you want to edit and press “OK” button.
4. Make necessary adjustment. Save the message.
5. Your message has been modified.

How to Delete Your Saved Message:

1. Press “Menu” button
2. When [1] Add Contents displays, press down button until you see [5] Delete Contents. Press “OK” button
3. When ① Delete Option displays, press “OK” button. Choose the message you want to delete and press “OK” button. When asked to delete again, press “OK” to confirm.
 - a. You can delete all your messages by scrolling down to ② Delete all and pressing “OK” button. When asked to delete, press “OK” to confirm.
4. Your message is deleted.

How to Add Icons, Symbols, in Your Messages:

1. Follow steps 1~3 from “How to Add Messages”
2. On the remote controller, find “Move” button or “Icon” button. You will see pre-loaded icons on the sign. Scroll through and find one you like. Press “OK” button.
3. Icon is added in your message.

How to Turn Off/On the Sound:

1. Press “Menu” button
2. When [1] Add Contents displays, scroll down until you see [9] Setting up. Press “OK” button.
3. When ① Reservation displays, press down button until you see ② Sound. Press “OK”
4. There should be an O next to Sound. Press “OK” button. The O will turn into X.
 - a. To hear the sound again, press “OK” button when X is displayed. X will turn into O and you will hear the sound again.

How to Automatically Turn Your Sign On/Off

1. Press “Menu” button
2. When [1] Add Contents displays, scroll down until you see [9] Setting up. Press “OK” button.
3. When ① Reservation displays, press “OK” button.
4. There should an X next to Reservation. Press “OK” button. The X will turn into O.
 - a. To get rid of your timer, press “OK” button when O is displayed. O will turn into X.
5. Press the red ESC button to return to [9] Setting Up. Scroll up and choose [8] Set Time. Press “OK” button
6. When ① Set time is displayed, scroll down until you see ③ Set timer on. Press “OK” button. Set your timer according to the time you want it to turn on. Press “OK” button.
7. When ③ Set timer on displays, Press down “Effect” button until you see ④ Set timer off. Press “OK” button. Set your timer according to the time you want it to turn off. Press “OK” button.
8. Your sign will automatically turn on and off according to the time you’ve set.

How to Change Your Password:

**** PASSWORD IS NOT NECESSARY. YOU DO NOT HAVE TO SET IT UP. HOWEVER, IF YOU CHOOSE TO DO SO, PLEASE REMEMBER YOUR PASSWORD.**

Menu Tree

[1] Add Contents

- ① Add Message
- ② Add dual Message
- ③ Add Image
- ④ Add Picture
- ⑤ Add Video
- ⑥ Display date
- ⑦ Display Time
- ⑧ Add Dday
- ⑨ Add Dtime
- ⑩ Add Temperature
- ⑪ Add Humidity
- ⑫ Add Event

[2] Modify Contents

[3] Insert Contents

[4] Index Contents

[5] Delete Contents

- ① Delete Option
- ② Delete All

[6] Stop Watch

- ① Increment Mode
- ② Decrement Mode

[7] Password

[8] Set Time

- ① Set Time
- ② Set Date
- ③ Set timer on
- ④ Set timer off

[9] Setting up

- ① Reservation
- ② Sound
- ③ Direction
- ④ Password
- ⑤ Brightness

[10] ~ [12] Not Necessary. Please do not modify anything on these menus.